

# PGV

VACUUM CALIBRATION PUMP -0.95 ... 0 BAR / -13.7 ... 0 PSI



126

**The PGV** is a highly efficient vacuum pump generating vacuum quickly using a pulling action. The extensive volume control provides fine adjustment of the generated vacuum. The compact, sturdy and lightweight construction is designed for use in tough field environments.

## Specifications

PGV	
Output pressure:	-0.95 ... 0 bar / -13.7 ... 0 psi
Pressure media:	Air
Output connector:	Bx G1/8" male for Beamex 40 bar (600 psi) hoses
Dimensions:	Diameter 35 mm / 1.38" Length, min 230 mm / 9.06" Length, max 322 mm / 12.68"
Weight:	340 g / 0.75 lb
Standard delivery:	<ul style="list-style-type: none"><li>• spare part set</li></ul>
Optional accessories:	<ul style="list-style-type: none"><li>• hard carrying case</li><li>• 40 bar pressure hoses and fittings"</li></ul>

For up-to-date list and prices for accessories, please visit webshop at [shop.beamex.com](http://shop.beamex.com)

Please see 'Pressure fittings guide' at [shop.beamex.com](http://shop.beamex.com)